



Product Data Sheet

RF356I4

Bouton panique bracelet radio: montre, pendentif, porté à la ceinture ou mural,

Overview

The Panic Button is a water-resistant wireless device used for activating police, medical, or auxiliary alarms throughout the premises. When the panic button is pressed, the LED mounted under the front cover will blink and an alarm signal is transmitted.

The status of the battery is sent in every transmission. The battery is field replaceable.

The button has five adapters which easily fit onto the panic button. Using these adapters the panic button can be mounted on the wall, worn as a belt clip, as a watch, or as a pendant.



Caractéristiques

RF356I4

Bouton panique bracelet radio: montre, pendentif, porté à la ceinture ou mural,

Caractéristiques techniques

Comment commander

Référence	Description
RF356I4	Bouton panique bracelet radio: montre, pendentif, porté à la ceinture ou mural, LED de contrôle.

